

# Product Specification



## Wireless Kinetic Switch Wall Switch



### Product Features

- Wireless Push Button
- NO power or batteries required
- Add a switch anywhere (no chasing walls, no cabling required)
- Mount the switch wherever you want
- Can be screwed or attached to the wall with double sided tape
- Pair Multiple Switches with the one receiver for multi-way switching
- Dimming available in the Wide Model only
- Works together with the S-Tech range of Kinetic Wireless Receivers or Doorbell
- Range: ≤30m Indoor, ≤80m Outdoor

### Narrow Wall Switch

- Join multiple switches together to create additional switches in one bank
- Not suitable for dimming

### Wide Wall Switch

- Suitable for dimming



### Specification Overview



Model	Type	Dimensions	Comments
KIN-SW-N-W	Narrow Wall Switch – 1 Gang	86 x 29 x 16mm	Mount anywhere, not suitable for dimming
KIN-SW-W-W	Wide Wall Switch – 1 Gang	86 x 86 x 16mm	Mount anywhere, suitable for dimming